




Kinsley Dining Counter Bar Arm Chair
Fauteuil de comptoir de bar Kinsley
Kinsley Comedor Mostrador Bar Sillón

Assembly Instructions
instructions de montage
Instrucciones de montaje







(A) x1




(B) x1



(C) x1




(D) x1



(E) x2

Hardware Included
Matériel inclus
Herrajes incluidos



Items Not Included
Articles non inclus
Artículos no incluidos



(9532) x1



(95326) x1



(214112) x18

Use drill on low speed.
DO NOT USE IMPACT DRILL!
Utilisez la perceuse à basse vitesse.
N'UTILISEZ PAS DE PERCEUSE À IMPACT !
Utilice el taladro a baja velocidad. **¡NO UTILICE TALADRO DE IMPACTO!**

- 1** (A) x1
(B) x1
(C) x1
(D) x1
(E) x2

