



Kinsley Dining Counter Bar Side Chair
Chaise d'appoint de comptoir de salle à manger Kinsley
Kinsley Comedor Contador Bar Silla lateral


Assembly Instructions
instructions de montage
Instrucciones de montaje

BERLIN
GARDENS







(A) x1




(B) x1



(C) x1




(D) x1



(E) x2


Hardware Included
Matériel inclus
Herrajes incluidos



(9532) x1




(95326) x1



(214112) x18

Items Not Included
Articles non inclus
Artículos no incluidos



Use drill on low speed.
DO NOT USE IMPACT DRILL!
Utilisez la perceuse à basse vitesse.
N'UTILISEZ PAS DE PERCEUSE À IMPACT !
Utilice el taladro a baja velocidad. **¡NO UTILICE TALADRO DE IMPACTO!**

- 1** (A) x1
(B) x1
(C) x1
(D) x1
(E) x2

