







ADA Octagon Picnic Table  
Table de pique-nique octogonale ADA  
Mesa de picnic octágono ADA

Assembly Instructions  
instructions de montage  
Instrucciones de montaje


BERLIN  
GARDENS






Hardware Included  
Matériel inclus  
Herrajes incluidos

(2516200) x4




(61516) x4




x2




(48100) x48




(02290) x2




(9532) x1





Items Not Included  
Articles non inclus  
Artículos no incluidos





#2 Square Drive Bit  
Embout d'entraînement carré #2  
Punta cuadrada n.º 2




**1** (A) x2  
(B) x1  
(C) x1  
(E) x1



**1a** (E) x1



**2** (D) x1



**2a**

