



Comfo Back & Cozi Back Three Seat Glider Assembly Guide



Hardware Included


- 8 - 5/16" x 2" Bolts
- 8 - 5/16" x 2 1/2" Bolts
- 2 - 1/4" x 4 1/2" Bolts
- 2 - 1/4" x 3 1/2" Bolts
- 8 - 1/4" x 3" Bolts
- 12 - 5/16" Flange Nuts
- 8 - 5/16" Lock Nuts
- 4 - 5/16" Cap Nuts
- 4 - 5/16" Aluminum Spacers
- 12 - 1/4" Flange Nuts
- 4 - Glider Brackets
- 1 - Allen Wrench

Tools Required



Step 1


A. Fasten the Arm and Leg Assembly to the Seat and Back using 1/4" bolts (sizes are specified below.) Using a hammer, firmly tap the bolts until they are flush with the poly surface. Securely tighten using 1/4" flange nuts.




B. Insert 5/16" x 2 1/2" bolts into the pre-drilled holes located at the very bottom of the legs. Tighten using 5/16" flange nuts. Ensure that the bolts are turned inwards.

C. Fasten the Back to the Seat using 2 - 1/4" x 3" bolts and tighten using 1/4" flange nuts.

D. Repeat A. & B. to fasten the second Arm and Leg Assembly to the Seat and Back




Step 2



A.
Attach the two cross supports to the glider bases using 8 - 5/16" x 2" Bolts and 8 - 5/16" Flange Nuts.


B.
Attach the 4 - glider stops to the glider bases using 4 - 1/4" x 3 1/2" bolts and 4 - 1/4" Flange Nuts.

Step 3



Attach the four glider brackets to the glider base by first sliding the bracket onto a 5/16" x 2 1/2" bolt. Next slide a round 5/16" aluminum spacer onto the bolt and insert the bolts into the pre-drilled holes of the glider base. Firmly tighten with a 5/16" lock nut and place a 5/16" cap nut at the end of the bolt sequence.

Step 4



Slide the Base Assembly underneath the seat of the glider, ensuring the front of the base is pointed forward. Insert the 5/16" x 2 1/2" bolts that are installed at the bottom of the glider legs, into the lower holes of the Glider Brackets. Securely tighten using 4 - 5/16" Lock Nuts.